



25



26 Accessory

## Prima Pappa Diner

- |              |              |
|--------------|--------------|
| 1 EMPP35     | 14 SAPI5897  |
| 2 ARPI0355   | 15 SPST5942J |
| 3 SPST5025XD | 16 SPST5729J |
| SPST5025XS   | 17 SOTF0130  |
| 4 SPST5024D  | 18 SAPI5934  |
| SPST5024S    | 19 SPST5729K |
| 5 SPST5459   | 20 SAPU5298X |
| 6 SPST5458   | 21 SAPU5298X |
| 7 SAPU5457GL | 22 IRTR0001B |
| 8 SPST5727   | 23 SPST5171  |
| 9 SPST5728   | 24 SPST5172  |
| 10 SOTF0137  | 25 MUCI5P11  |
| 11 SAPU5730  | 26 SPST4645  |
| 12 SPST5942K | 27 SPST4725  |
| 13 SAPI5934T |              |

EN Spare parts available in different colours to be specified when ordering.  
 ES Repuestos disponibles en otros colores que se especificarán en el pedido.  
 FR Pièces de rechange disponibles en plusieurs couleurs à spécifier dans la demande.

# Prima Pappa Diner

